

Friends Conference Room

Media Equipment Guide



LAPTOP & DATA MONITOR OPERATION



1. Turn on the TV/Data Monitor
2. Connect cable to the "VGA" input on the front of the TV/Data Monitor
(Cable is located in the cabinet under the monitor)
3. Connect the other end of the cable to your laptop
4. Turn on laptop
5. Press "Enter/Source" button on the monitor until you get to the "PC 2" input
6. If picture does not appear on the monitor and your laptop screen press "Fn" & the F-Key (F1-F12) with a monitor symbol on it simultaneously
Please allow several seconds for synchronization
Repeat step 6 until image appears on both screens

DVD/VHS PLAYER OPERATION



1. Turn on the TV/Data Monitor
2. Turn on the DVD/VHS player (Located below the monitor)
3. Press "Enter/Source" button on the monitor until you get to the "AV1" input
5. Play DVD or VHS video (Use remote control or buttons on player)
6. Adjust the volume by using the volume controls on the monitor

TV OPERATION

1. Turn on the TV/Data Monitor
2. Press the "Enter/Source" button until you get to the "ANT 1" input
3. Use the channel up/down buttons to choose a channel
Note: Reception varies among channels

If you experience any problems or need assistance please call **x5050**